


42	MONITOR AMBIENTAL Y ESTADO DEL SIES	42
41		41
40		40
39		39
38	CONVERSOR DC/DC 1	38
37		37
36		36
35		35
34	CONVERSOR DC/DC 2	34
33		33
32		32
31		31
30		30
29		29
28	INVERSOR 1	28
27		27
26		26
25		25
24	INVERSOR 2	24
23		23
22		22
21		21
20	TABLERO DE MANIOBRA SIES	20
19		19
18		18
17		17
16	TABLERO DE DISTRIBUCION 220 VAC SEGUROS	16
15		15
14		14
13		13
12	TABLERO DISTRIBUCION 48 DC1 BORNERAS FRONTERA	12
11		11
10		10
9		9
8	TABLERO DISTRIBUCION 48 DC2 BORNERAS FRONTERA	8
7		7
6		6
5		5
4	TABLERO DISTRIBUCION 125VDC BORNERAS FRONTERA	4
3		3
2		2
1		1



SIEMENS DISTRIBUCION DE EQUIPOS Y TABLEROS EN EL RACK

NOTA: LOS INTERRUPTORES [A-B-C-D-E-F-G-H DOBLE VIA MANUAL] DEBEN IR EN UN UNICO TABLERO DENOMINADO TABLERO DE MANIOBRAS DEL SIES